

# TECHNICAL TIPS WITH PETER TAYLOR

*A resource of good ideas and functional ways to assist in the restoration of our heritage vehicles. I acknowledge that these tips have been gleaned from various club and car related magazines, and also from my own experiences. Authors and/or publications will be credited with the tip, when known. The Chevrolet Club does not necessarily endorse any or all of these tips.*

## CHEVROLET CASTING NUMBERS FOR IDENTIFYING THE YEAR AND APPLICATION, BLOCK AND HEAD

CYLINDER	HEAD		CYLINDER	BLOCK	
1917, 18, 19	338048	D V8	1924	327773	
1922	381099	FB Three Port	1927	348709	
1916-21	333776		1928	348532	
1922-27	345453	Single Port 1 1/2" Valve	1929	835501	All
1927	346886	Single Port AA, LM	1930-31	836409	All
		1 2 1/32" Valves	1932	836573	All
1928	348540	Two Port	1933-34	837231	CA, DA Master & Truck
1929	835503	All	1933	473180	CC Standard
1930-31	836273		1934	473741	DC Standard
	836275	All	1935-36	836010	All
1932	836718	All	1937-38	838710	All
1933	836961	CA Master	1939	838941	All
1933	600569	CC Standard	1940	839132	411
1934	837230	DA Master	1941	839400	216 Pass. Truck
1934	473740	DC Standard	1941	3660439	235 Truck
1935 early	837230	Master 40 Angle Seats	1942-47	839770	216 Pass, Truck
1935-36	837981	All 30 Angle Seats		839910	216 Pass, Truck
1937 early	838355	All	1942-47	3835335	235 Truck
1937-40	838773	All		839751	235 Truck
1941-48	839401	All 216, 235	1948-49	3835253	216 Pass, Truck
1949	383540	All 216, 235	1948-49	3835309	235 Truck
1950-53	383551	All 216	1950-51	3692703	235 Pass. With Powerglide
1950-52	383549	235	1950-51	3835497	216 Pass, Truck
1950-52	383590	235	1950-51	3692713	235 Truck
1953	370188	235	1952	3835692	235 Pass. With P/glide, Truck
1954-55	383591	235	1952-53	3835849	216 Pass, Truck
1954	383549	261 Truck	1953	3701946	235 Exc. Powerglide
1955	370857	261 Truck	1953	3701481	235 with Powerglide
1956	383684	235	1954	3701481	235 with Powerglide
1953		Corvette 6 Cylinder		3835911	235 with Powerglide
1954/1955	383624	Corvette 6 Cylinder	1954	3701481	235 Exc. Powerglide
1955	370352	Pass, Corvette V8 265	1954-55	3702436	261 Truck
				3703414	261 Truck
1956	372530	Pass, Corvette V8 265	1955	3835911	235 Exc. Powerglide
	3837064	Pass, Corvette V8 265		3733949	235 Exc. Powerglide
			1955	3836233	235 with Powerglide
1957	373155	Pass, Truck V8 283	1955-56	3836340	261 Truck
1957	373153	Pass w/14BC V8 283	1953-55	3835911	235 Corvette 6 cylinder
1957	374099	Pass, Corvette 283 V8	1955	3703524	265 V8 Pass, Corvette
		With Dual 4bbl Carbs	1956	3720991	265 V8 Corvette
			1957	3731548	283 V8 with 2bbl Carb
			1957	3867802	283 V8 with Fuel Injection

*With Thanks to the VCCA - Generator & Distributor*